

17th Edition Testers

Accessories

Calibration Equipment



**Thank you for buying one of our products. For safety and full understanding of its benefits please read this manual before use. Technical support is available from 01923 441717 and**

## **1. INTRODUCTION**

### **1.1 Inspection**

Examine the shipping carton for any sign of damage. Inspect the unit

## ELECTRICAL

## 2. PRODUCT SPECIFIC SAFETY INFORMATION

**Measurement Category III (CAT III)** is applicable to test and measuring equipment connected to the distribution part of the building's low-voltage MAINS installation.

**Measurement Category IV (CAT IV)** is applicable to test and measuring equipment connected at the source of the building's low-voltage MAINS installation.

### 2.1 Precautions

This product has been designed with your safety in mind, but please pay attention to the following warnings and cautions before use.

#### **Warning**

Before use check the unit for cracks or any other damage. Make sure the unit is free from dust, grease and moisture. Also check any associated leads and accessories for damage. Do not use if damaged.

#### **Warning**

Do not use if the battery/fuse cover is not fitted.

#### **Warning**

When this unit is used in combination with test leads, the measurement category of the combination is the lower measurement category of either this unit or the test leads used. Likewise, if test lead accessories such as crocodile clips are also used, the measurement category will be the lowest measurement category in that combination.

**Warning**



### 3.5 Description of LCD Symbols

Set the rotary switch to either AC A or DC A and the required

